

VIDEO CONTENT ANALYTICS

Region Entrance/Exit

IP

The Region Entrance/Exit feature enables you to draw a virtual quadrant anywhere within the camera field of view. The camera monitors this detection zone and can be set to sound an alarm, start recording or send a notification whenever a person or object enters or exits the zone.

Region Entrance/Exit is ideal for detecting events such as:

- A person attempts to climb over a barricade, scale a fence, or cross a facility perimeter
- A person enters a restricted area, such as a stock room, medical supply closet, or server room
- A person or vehicle enters an office building, retail store or industrial property after hours
- A person is loitering in an unauthorized area
- A vehicle enters a parking lot via the exit, or exits in the wrong direction



Applications

- Airports
- Banks
- Childcare Facilities
- Chemical Plants
- Construction Sites
- Event Management
- Office Buildings
- Power Plants
- Schools
- Shopping Centers
- ...and more

Features & Benefits:*

- Easily configure Region Entrance/Exit to:
 - Designate an area that is sensed for objects that move into or out of it
 - Set up a schedule for when the camera senses entrance/exit
- Adjustable camera sensitivity allows you to set maximum and minimum size of objects to be detected, preventing false alarms and/or event triggers
- Region Entrance/Exit analytics are more reliable than traditional motion detection, because sensitivity settings can be configured to reduce the incidence of false alarms
- The VCA Search feature saves time by allowing you to quickly find, review and download video of Region Entrance/Exit events
- The Video Playback feature allows you to easily review and analyze Region Entrance/Exit events
- Customized triggered event recording reduces hard drive storage requirements

**Alibi DVRs, NVRs and IP cameras can perform Region Entrance/Exit analysis*